

INSTALLATION INSTRUCTIONS

REINFORCED BOLLARD

REF#	QTY	DESCRIPTION
1	1	REINFORCED BOLLARD

STEP 1:

DIG A HOLE IN THE LOCATION WHERE THE BOLLARD IS TO BE USED (MINIMUM OF 18" DEEP AND 8" WIDE).

STEP 2:

CENTER THE BOLLARD INTO THE HOLE, MAKING SURE THAT THE BOLLARD IS STANDING UP STRAIGHT.

STEP 3:

FILL THE HOLE SURROUNDING THE BOLLARD WITH CONCRETE. FOR ADDED STABILITY A LENGTH OF REBAR CAN BE PLACED THROUGH THE SMALL HOLE NEAR THE BASE OF THE BOLLARD PRIOR TO POURING CONCRETE.

Your 100% recycled plastic reinforced bollard will give you many years of pleasure and pride, knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.