




## ASSEMBLY INSTRUCTIONS MALIBU BENCH - ARMRESTS

**STEP 1:** ALIGN HOLE ON BACK OF ARMREST WITH THE HOLE ON THE BACK OF THE BENCH LEG. INSERT CARRIAGE BOLT. PLACE WASHER & NUT ON CARRIAGE BOLT. **DO NOT TIGHTEN!!**

**STEP 2:** ALIGN HOLE ON BOTTOM OF ARMREST WITH THE HOLE ON THE SEAT OF THE BENCH LEG. INSERT CARRIAGE BOLT. PLACE WASHER & NUT ON CARRIAGE BOLT. **DO NOT TIGHTEN!!**

**STEP 3:** REPEAT STEPS 1 & 2 FOR THE OTHER ARMREST.

**STEP 4:** NOW YOU MAY GO BACK AND FINISH TIGHTENING THE NUTS THE REST OF THE WAY. **BE CAREFUL NOT TO OVER TIGHTEN!!**

REF#	QTY	DESCRIPTION
1	2	ARMRESTS
		HARDWARE KIT
2	4	 5/16" X 3-1/2" CARRIAGE BOLT
3	4	 5/16" FLAT WASHER
4	4	 5/16" HEX NUT

*Your 100% recycled plastic picnic table will give you many years of pleasure and pride, knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

