

ASSEMBLY INSTRUCTIONS INGROUND ROCK ISLAND BENCH

STEP 1: PLACE THE BENCH LEGS DOWN SO THE HOLES IN THE BACK ARE PARALLEL TO THE GROUND WITH THE “SPIKED” END SLANTING AWAY FROM YOU. (ESTIMATE SPACING).

STEP 2: PLACE 3 OF THE 2 X 6 BOARDS ONTO THE SEAT ALIGNING THE HOLES IN THE BENCH LEGS WITH THE PILOT HOLES IN THE 2X6’S. FASTEN THE BOARDS TO EACH BENCH LEG FROM THE UNDERSIDE OF THE BENCH LEGS USING 6 OF THE 2-1/4” SCREWS PER BENCH LEG. USE OF A POWER DRIVER WITH A PHILLIPS #3 (LARGE) BIT IS RECOMMENDED – **DO NOT OVER TIGHTEN.**

STEP 3: PLACE ONE OF THE 2 X 6 BOARDS ONTO THE BACK OF THE BENCH. ALIGN THE HOLES IN THE BACK OF THE BENCH LEGS WITH THE PILOT HOLES IN THE BOARDS. ATTACH THE BOARD TO THE BENCH LEGS USING 2 OF THE 2-1/4” SCREWS PER BENCH LEG. REPEAT FOR THE REMAINING 2 X 6.

STEP 4: PUT THE BENCH EXACTLY WHERE YOU WANT TO INSTALL IT (STILL ON ITS BACK). MARK THE GROUND WHERE THE “SPIKED” ENDS ARE. DIG POST HOLES APPROXIMATELY 20” DEEP WHERE YOU MADE YOUR MARKS. PUT THE “SPIKED” ENDS INTO THE HOLES AND MEASURE THE HEIGHT FROM THE FRONT OF THE SEAT TO THE GROUND. ADD OR REMOVE MATERIAL FROM THE HOLES UNTIL THE BENCH (TOP OF FRONT SEAT BOARD) IS APPROXIMATELY 17” TO 17-1/2” ABOVE THE GROUND. USE A SMALL 6” TORPEDO LEVEL TO CHECK FINAL VERTICAL AND HORIZONTAL ALIGNMENT OF THE BENCH LEGS AND ADJUST AS NECESSARY. FILL THE HOLES 2/3 FULL OF “DRY” CONCRETE MIX. (MAKE SURE TO WIPE ANY DUST OFF OF BENCH BEFORE ADDING WATER) ADD WATER ACCORDING TO DRY MIX INSTRUCTIONS. FILL HOLES THE REST OF THE WAY WITH DIRT. KEEP OFF OF BENCH FOR AT LEAST A DAY.

WE RECOMMEND SCREWING WOOD STAKES TO BENCH LEGS TO BRACE THEM FROM MOVING WHILE CONCRETE SETS AND LEAVE ATTACHED TO BENCH FOR 24 HOURS OR UNTIL CONCRETE IS SET ENOUGH TO HOLD BENCH IN PLACE. REMOVE WOOD STAKES.

OPTIONAL: A HOLE CAN BE DRILLED THROUGH THE BASE OF THE “SPIKED” ENDS AND A LENGTH OF PIPE OR REBAR CAN BE PLACED THROUGH THE HOLE TO ASSIST IN THEFT PREVENTION.

NOTE: PROFILES MAY BE DIRECTIONAL
AND YOU MAY NEED TO TURN THEM END-FOR-END IF THEY DO NOT LINE UP SQUARELY.

*Your 100% recycled plastic park bench will give you many years of pleasure and pride,
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

	4'	6'	8'	
REF#	QTY	QTY	QTY	DESCRIPTION
1	5	5	5	2" X 6" PROFILE
2	2	3	4	INGROUND BENCH LEG
3	20	30	40	HARDWARE KIT #14 X 2-1/4" SS FH PHILLIPS SCREW 