


ASSEMBLY INSTRUCTIONS INGROUND MALIBU BENCH

STEP 1: PLACE THE BENCH LEGS DOWN SO THE HOLES IN THE BACK ARE PARALLEL TO THE GROUND WITH THE “SPIKED” END SLANTING AWAY FROM YOU. (ESTIMATE SPACING).

STEP 2: PLACE THE FIRST 2” X 4” PROFILE ON THE BACK OF THE SEAT ON THE LEGS BUTTED UP TO THE “STUB” THAT DIVIDES THE SEAT AND BACK, MAKE SURE THE “MOLD” SEAM IS FACING DOWN. INSERT SCREWS INTO PREDRILLED HOLES IN THE BENCH LEGS. DO NOT FULLY TIGHTEN.

STEP 3: PLACE A SECOND 2” X 4” PROFILE TOWARD THE BOTTOM OF THE BACK ON THE LEGS BUTTED UP TO THE “STUB” THAT DIVIDES THE SEAT AND BACK. MAKE SURE THE “MOLD” SEAM IS FACING THE BACK. INSERT SCREWS INTO PREDRILLED HOLES IN THE BENCH LEGS. DO NOT FULLY TIGHTEN.

STEP 4: PLACE A MALIBU BOARD ONTO THE SEAT OF THE LEGS. INSERT SCREWS INTO PREDRILLED HOLES IN THE BENCH LEGS. REPEAT WITH MALIBU BOARD ON THE BACK OF THE BENCH.

	4'	5'6'	
REF#	QTY	QTY	DESCRIPTION
1	1	1	RIGHT INGROUND MALIBU LEG
2	1	1	CENTER INGROUND MALIBU LEG
3	1	1	LEFT INGROUND MALIBU LEG
4	2	2	MALIBU BOARD
5	6	6	2" X 4" PROFILE
			HARDWARE
6	40	40	 #14 X 2-1/4" SS PHILLIPS SCREW

STEP 5: ADD THE REMAINING 2” X 4” PROFILES (2 ON THE SEAT AND 2 MORE ON THE BACK), PLACING THEM SO YOU HAVE EQUAL SPACING BETWEEN ALL BOARDS. INSERT SCREWS INTO PREDRILLED HOLES IN THE BENCH LEGS. DO NOT FULLY TIGHTEN

*HOLD OR CLAMP THE PROFILES SECURELY WHILE TIGHTENING SCREWS. USE OF A POWER DRIVER WITH A PHILLIPS #3 (LARGE) BIT IS RECOMMENDED. ONCE THE BENCH IS FULLY ASSEMBLED TIGHTEN ALL SCREWS, SHIFTING BENCH AS NECESSARY TO INSURE A NEAT SQUARE APPEARANCE. – **DO NOT OVER TIGHTEN.**

STEP 6: PUT THE BENCH EXACTLY WHERE YOU WANT TO INSTALL IT (STILL ON ITS BACK). MARK THE GROUND WHERE THE “SPIKED” ENDS ARE. DIG POST HOLES APPROXIMATELY 20” DEEP WHERE YOU MADE YOUR MARKS. PUT THE “SPIKED” ENDS INTO THE HOLES AND MEASURE THE HEIGHT FROM THE FRONT OF THE SEAT TO THE GROUND. ADD OR REMOVE MATERIAL FROM THE HOLES UNTIL THE BENCH (TOP OF FRONT SEAT BOARD) IS APPROXIMATELY 17” TO 17-1/2” ABOVE THE GROUND. USE A SMALL 6” TORPEDO LEVEL TO CHECK FINAL VERTICAL AND HORIZONTAL ALIGNMENT OF THE BENCH LEGS AND ADJUST AS NECESSARY. FILL THE HOLES 2/3 FULL OF “DRY” CONCRETE MIX. (MAKE SURE TO WIPE ANY DUST OFF OF BENCH BEFORE ADDING WATER) ADD WATER ACCORDING TO DRY MIX INSTRUCTIONS. FILL HOLES THE REST OF THE WAY WITH DIRT. KEEP OFF OF BENCH FOR AT LEAST A DAY.

WE RECOMMEND SCREWING WOOD STAKES TO BENCH LEGS TO BRACE THEM FROM MOVING WHILE CONCRETE SETS AND LEAVE ATTACHED TO BENCH FOR 24 HOURS OR UNTIL CONCRETE IS SET ENOUGH TO HOLD BENCH IN PLACE. REMOVE WOOD STAKES.

OPTIONAL: A HOLE CAN BE DRILLED THROUGH THE BASE OF THE “SPIKED” ENDS AND A LENGTH OF PIPE OR REBAR CAN BE PLACED THROUGH THE HOLE TO ASSIST IN THEFT PREVENTION.

*Your 100% recycled plastic park bench will give you many years of pleasure and pride,
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*