


ASSEMBLY INSTRUCTIONS INGROUND TRAIL BENCH

STEP 1: PLACE THE 2 (OR 3 DEPENDING ON MODEL) INGROUND LEGS DOWN SO THE HOLES IN THE TOP OF ARE VERTICAL TO THE GROUND WITH THE “SPIKED” END SLANTING AWAY FROM YOU. (ESTIMATE SPACING).

STEP 2: PLACE A 3” X 4” PROFILE ON THE GROUND IN FRONT OF THE BENCH LEG TOPS, MAKING SURE THE “MOLD” SEAM IS FACING THE TOP OF THE BENCH LEG. (THE “MOLD” SEAM SHOULD BE FACING THE GROUND WHEN THE BENCH IS INSTALLED IN AN UPRIGHT POSITION).

STEP 3: SLIDE PROFILE TO ALIGN PILOT HOLES WITH THE CORRESPONDING HOLES OF THE BENCH LEGS. FASTEN THE BOARD TO EACH BENCH END FROM THE UNDERSIDE OF THE BENCH ENDS USING 6 OF THE 3” LAG SCREWS & WASHERS PER BENCH END.

	4'	6'	
REF#	QTY	QTY	DESCRIPTION
1	2	3	INGROUND BENCH END
2	3		3” X 4” X 4’ PROFILE
2		3	3” X 4” X 6’ PROFILE
3	12	18	HARDWARE KIT  3/8” X 3” LAG SCREW 3/8” FLAT WASHER
4	12	18	

STEP 4: PLACE THE REMAINING 3” X 4” PROFILES ON THE BENCH LEGS, MAKING SURE THE “MOLD” SEAM IS FACING DOWN. REPEAT STEPS 2 & 3.

STEP 5: ONCE THE BENCH IS ASSEMBLED PLACE THE BENCH WHERE YOU WANT TO INSTALL IT. MARK THE GROUND WHERE THE “SPIKED” ENDS ARE. DIG POSTHOLES APPROXIMATELY 18 INCHES DEEP WHERE YOU MADE YOUR MARKS. CHECK THE DISTANCE FROM THE GROUND TO THE TOP OF THE BENCH SEAT. WE RECOMMEND THE SEAT HEIGHT BE APPROXIMATELY 17”, BUT NO LOWER THAN 15”. ADD OR REMOVE DIRT (OR ADD SMALL ROCKS) TO ADJUST HEIGHT. PLACE A STRAIGHT ITEM ACROSS THE SEAT TO ENSURE THE LEGS ARE ALL AT THE SAME HEIGHT TO PREVENT BOWING OR SAGGING IN THE MIDDLE. PLACE THE “SPIKED” ENDS IN THE HOLES, FILL WITH DIRT OR CONCRETE FOR A MORE PERMANENT INSTALLATION. USE A LEVEL TO CHECK FINAL ALIGNMENT OF THE BENCH AND ADJUST AS NECESSARY.

NOTE: PROFILES MAY BE DIRECTIONAL
AND YOU MAY NEED TO TURN THEM END-FOR-END IF THEY DO NOT LINE UP SQUARELY.

*Your 100% recycled plastic park bench will give you many years of pleasure and pride,
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

